

JOB SAFETY ANALYSIS (JSA) FORM					Rev 1 Feb 24
Unit/Area:	Specific Location:	Work Authorizer (if applicable):	Supervisor / Work Lead:	Date:	
Job Description for Tasks with High Potential Consequence (i.e., life-altering injuries or Consequence Level 1 process safety events including HC 1&2 events) (include Equipment Numbers as Practical):					
Check LSRA(s) that apply and review Start Work Check(s). Complete Page 2 with any additional task steps with high potential consequence or if there is no applicable LSRA.					
 Confined Space Entry Obtain authorization before entering a confined space ☐		 Bypassing Safety Controls Obtain authorization before overriding or disabling safety controls ☐		 Energy Isolation Verify isolation and zero energy before work begins ☐	
<ol style="list-style-type: none"> 1. I confirm energy sources are isolated 2. I confirm the atmosphere has been tested and is monitored 3. I check and use my breathing apparatus when required 4. I confirm there is an attendant standing by 5. I confirm a rescue plan is in place 6. I obtain authorization to enter 		<ol style="list-style-type: none"> 1. I understand and use safety-critical equipment and procedures which apply to my task 2. I obtain authorization before: <ul style="list-style-type: none"> • Disabling or overriding safety equipment • Deviating from procedures • Crossing a barrier 		<ol style="list-style-type: none"> 1. I have identified all energy sources 2. I confirm that hazardous energy sources have been isolated, locked, and tagged 3. I have checked there is zero energy and tested for residual or stored energy 4. I never remove or tamper with energy control devices without authorization 5. I confirm equipment is back to safe operating condition prior to re-energizing 	
 Safe Mechanical Lifting Plan lifting operations and control the area ☐		 Hot Work Control flammables and ignition sources ☐		 Working Around Mobile Equipment See and be seen; maintain a safe distance ☐	
<ol style="list-style-type: none"> 1. I confirm that the equipment and load have been inspected and are fit for purpose 2. I only operate equipment that I am qualified to use 3. I establish and obey barriers and exclusions zones 4. I never walk under a suspended load 5. I understand the lift plan prior to starting work and keep hands off load unless authorized 6. I establish and maintain communication with lifting and rigging personnel 		<ol style="list-style-type: none"> 1. I identify and control ignition sources 2. Before starting any hot work: <ul style="list-style-type: none"> • I confirm flammable material has been removed or isolated • I obtain authorization 3. Before starting hot work in a hazardous area, I confirm: <ul style="list-style-type: none"> • A gas test has been completed • Gas will be monitored continually 		<ol style="list-style-type: none"> 1. I plan work to separate workers and mobile equipment 2. I only operate mobile equipment if qualified and use spotters where required 3. I verify safety devices are functional on mobile equipment 4. I establish clear means of communication with equipment operator 5. I stay out of the equipment's exclusion zone while in operation 6. I confirm controls are in place to prevent unintentional movement of mobile equipment and/or loads 	
 Breaking Containment/OPE Manage ignition sources and exposure to energy & hazardous substances ☐		 Driving Follow safe driving rules ☐		 Work Authorization Work with a valid permit when required ☐	
<ol style="list-style-type: none"> 1. I verify opening/break location(s) 2. I confirm energy isolation is complete 3. I manage ignition sources and confirm gas testing is completed when required 4. I use appropriate PPE and defensive behaviors when opening process equipment 		<ol style="list-style-type: none"> 1. I always wear a seatbelt 2. I do not exceed the speed limit, and reduce my speed for road conditions 3. I do not use phones or operate devices while driving 4. I am fit, rested and fully alert while driving 5. I follow journey management requirements 		<ol style="list-style-type: none"> 1. I have confirmed if a permit is required 2. I am authorized to perform the work 3. I understand the permit 4. I have confirmed that hazards are controlled, and it is safe to start 5. I stop and reassess if conditions change 	
				 Line of Fire Keep yourself and others out of the line of fire ☐	
				<ol style="list-style-type: none"> 1. I position myself to avoid: <ul style="list-style-type: none"> • Moving objects • Vehicles • Pressure releases • Dropped objects 2. I establish and obey barriers and exclusion zones 3. I take action to secure loose objects and report potential dropped objects 	
Confirm these safeguards are in place and effective prior to starting work using the applicable SWC(s). During the task, if safeguards are no longer in place or effective, STOP Work.					

Are there any additional high potential consequence hazards present?

Electrical Energy 	Moving Objects 	Lighting & Visibility 	Simultaneous Operations (SIMOPS) or Stacked Work 
Stored Energy 	Hazardous Substances 	Noise & Vibration 	
Thermal Energy 	Radiation 		

High Potential Consequence Task Steps (Description)	Check off to indicate Hold Point	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards
	Hold Point ☐		
	Hold Point ☐		
	Hold Point ☐		
	Hold Point ☐		
	Hold Point ☐		

Confirm these safeguards are in place and effective prior to starting work using this JSA.
During the task, if safeguards are no longer in place or effective, STOP Work.

Lessons Learned (as needed): What improvements should be made for future work? Discussion leader to provide feedback to update planning package.

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work					Location:				
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
1	Hot work (burning, welding, grinding, etc.) within and around the GOLD project <div style="display: flex; flex-direction: column; align-items: center; gap: 10px;">    </div>	Open flame and/or sparks around combustible materials within and around the project resulting in a fire, personnel injury (burns including flash burns) and or damage to the facility.	P/F/E ☐	X			D/E /S/ W/A A A A	Prior to starting a task, Evaluate the Lifesaving Rules and actions (LSRA) start work Checks (SWC) that may apply to that task review START/STOP work expectations and implement, Verify & Validate (V&V) the appropriate behaviors and or control Safeguards per the ExxonMobil PSMS and site HSE Procedures during the pre-task brief Ensure JSA for specific LAI tasks address proper hazard control methods Utilize work permit process to control work activities. Ensure personnel are trained in the use of fire extinguishers and in the emergency response to fires.			X

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:				Date:		Reviewed By:				Date:	
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
							A/S	Keep combustible materials at least 35 feet away from hot work (housekeeping).			
							A/S	Keep flammable materials at least 50 feet away from hot work.			
							A/S	Personnel performing shall wear appropriate protective clothing and gloves to be defined in the JHA.			
							A	Only trained and authorized personnel shall be permitted to perform hot work.			
							A/D	A fire watch will be in place with requires gas monitoring equipment and will remain a minimum of 30 min after hot work has stopped.			
							A	Complete a Last Minute Risk Assessment (LMRA) prior to beginning each task.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

LAI HAZARD ANALYSIS												
Project Number:		Project Task: Hot Work					Location:					
Prepared By:			Date:		Reviewed By:				Date:			
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment			
				H	M	L			H	M	L	
2	Exothermic Welding (Cadweld)  	Skin/ bodily Burns, temperatures in excess of 2500 degrees Fahrenheit, Fire, Exposition, Flash burns, inhalation of smoke/fumes	P/F ☐		X		D/E /S/ W/A A A/D	Prior to starting a task, Evaluate the Lifesaving Rules and actions (LSRA) start work Checks (SWC) that may apply to that task review START/STOP work expectations and implement, Verify & Validate (V&V) the appropriate behaviors and or control Safeguards per the ExxonMobil PSMS and site HSE Procedures during the pre-task brief Ensure JSA for specific LAI tasks address proper hazard control methods GENERAL AND SAFETY INSTRUCTIONS: A. Only ERICO manufactured equipment and materials should be used to make CADWELD® connections. B. Do not connect items except as detailed in instruction sheets. Failure to comply with these instructions.			X	

Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:				Date:		Reviewed By:				Date:	
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								may result in improper and unsafe connections, damage to items being connected, bodily injury and property damage. C. Do not use worn or broken equipment which could cause leakage. D. Do not alter equipment or material without ERICO authorization. E. When using CADWELD® do not use welding material package if damaged or not fully intact. When using CADWELD® PLUS, do not tamper with or disassemble the welding material unit. F. Make connections in conformance with CADWELD instructions and all governing codes.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:				Date:		Reviewed By:				Date:	
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								<p>8. Review the SDS for the product and comply with all required PPE and controls</p> <p>9. Do not smoke when handling starting material.</p> <p>10. Avoid direct eye contact with "flash" of light from ignition of starting material.</p> <p>Welding material is an exothermic mixture and reacts to produce hot molten material with temperatures in excess of 1400°C (2500°F) and a localized release of smoke.</p> <p>These materials are not explosive. Ignition temperatures are in excess of 900°C (1650°F) for welding material.</p> <p>D Make sure there is proper mold fit and assembly of equipment.</p>			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
							D/A	Avoid moisture and contaminants in mold and materials being welded. Contact between hot molten metal and moisture or contaminants may result in spewing of hot material.			
							D/E	Base material thickness must be sufficient for the size and type of connection being made to prevent melt-through and leakage of hot molten metal.			

Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								Explosive powered tools shall not be used in the vicinity of other personnel unless specific safety precautions are identified within the JSA, documented, and implemented. Explosive powered tools are not to be used in situations where flammable or explosive gas, liquid or dust is present. Use the tool at least 100mm away from edges of concrete. Ensure the surface used is not hard or brittle. Do not use in existing holes. Do not use on soft or brittle substances/materials which allows the projectiles to pass through.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:			Date:			
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								Storage Tools and cartridges shall not be stored or used in explosive or flammable atmospheres. No explosive powered tool shall be stored in a loaded condition. Cartridges shall be stored in suitable metal containers which shall be kept locked. Charges and nails shall not be stored in the same container unless a proper divider/compartments is provided to separate the charges. Charges shall not be carrier loose in the operators' pocket.			
4	Use of propane fueled "weed Burner" torch, "rosebud" and/or Oxy-Fuel torch for preheating of welds.	Fire, gas leaks, thermal burns, explosion, hazardous/toxic fumes, oxygen deficiency	P/F ☐		X		D/E /S/ W/A	Prior to starting a task, Evaluate the Lifesaving Rules and actions (LSRA) start work Checks (SWC) that may apply to that task review START/STOP work expectations and implement, Verify & Validate (V&V) the appropriate behaviors and or			X

 Target:  = Personnel, F=Facilities and equipment, E=Environment

Control Type: D=Design hazard out or minimize, E=Engineering control, S=Safety device, W=Warning device, A=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								control Safeguards per the ExxonMobil PSMS and site HSE Procedures during the pre-task brief A Ensure JSA for specific LAI tasks address proper hazard control methods A Only trained and authorized employees will operate propane fueled "weed Burner" torch, "rosebud" and/or Oxy-Fuel torch for preheating of welds. A Read and understand owner/operator manual and SDS for equipment/fuel being used. A Ensure proper permit(s) are in place. A Ensure all Hot work controls as required by MS-HS-STD-0083 Hot Work Standard, and MS-HS-STD-0057 Welding and Gas Cutting			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:				Date:		Reviewed By:				Date:	
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
							A	Health and Safety Standard are in place prior to starting work.			
							A	Complete pre use checklist/ evaluation verified by Worley HSE representative prior to starting task.			
							A	Inspect the work location and ensure that hazards associated with SIMOPS have been mitigated.			
							A/W	Advise nearby personnel of torch operations in the area.			
							W/S	Ensure there is no fueling activities or other potential gas within 50ft of the torch activity.			
							A	Properly barricade the area with Danger Tape/Barricade			
							A	Inspect all tools, parts, and components prior to each use.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								Inspect fuel tank(s) for and cracking, rust, signs of wear such as bulges / dents, separation of welds. Check the hoses for cracks, cuts, thin areas, where the hose connects to the head and to the fittings to the valve and regulator. Check the torch head/ handle for any damage. Snoop all fitting to ensure there is no leakage. All proper PPE including safety glasses, Face shield or welding hood, Welding gloves, and FRC clothing shall be worn at all times. Secure cylinders in a level, upright position. Do not invert or lay cylinders on their sides. Do not apply flame to cylinders to check for leaks or to increase gas pressure.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								Keep torches, open flame, and sources of ignition away from cylinders, regulators, and hose. Do not operate torches or any equipment if the odor of LP-Gas is evident. Immediately shut off all valves and, using soapy water, check all equipment again for leaks. Cylinder valves must be protected. Do not hoist a cylinder by the valve. Do not leave the torch unattended while in operation. Maintain a fire watch for 30 minutes after the completion of hot work. Do not stand or prop the torch on the burner end while in operation.			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								<p>Equipment is for outdoor use only with adequate ventilation.</p> <p>Have a 20lb type ABC fire extinguisher at the use location, easily accessible to the person. operating the torch.</p> <p>Never direct torch flame toward any person, animal, flammable surface, or material.</p> <p>Do not use torch to remove paint.</p> <p>Oxy-Fuel Torches Torches must be lit with a friction lighter or other approved device and not by matches, cigarette lighters, or from hot work.</p> <p>As a minimum, suitable flashback arrestor which prevents flame flashbacks to be fitted at the pressure regulator outlet of each gas cylinder and manifold which supplies air, oxygen, or fuel gas to cutting torch, in accordance</p>			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								<p>with the manufacturer's instructions.</p> <p>A suitable check valve, non-return valve or any similar device which prevents the backflow of the gas into the hose, should be fitted between each gas torch inlet and gas hose, in accordance with the manufacturers' instruction</p> <p>Should a flashback occur, immediately turn off the oxygen and fuel gas valve at the torch and at the cylinders.</p> <p>Purge hose lines individually every time before lighting the torch. This will ensure that no oxy-fuel gas mixture is present in the hoses, which could cause an explosion.</p>			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:				Date:		
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								<p>Keep oxygen cylinders and fittings away from oil or grease. Oil or grease may ignite violently in presence of oxygen under pressure.</p> <p>Keep oily or greasy substances away from cylinders, cylinder valves, couplings, regulators, hose, and apparatus.</p> <p>Do not handle oxygen cylinders or related apparatus with oily hands or gloves.</p> <p>Oxygen cylinders should not be handled on the same platform with oil or be placed in a position where oil or grease from overhead cranes or belts may fall upon them.</p>			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:			Date:		Reviewed By:			Date:			
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								<p>Regulators shall be removed, and valve protection caps shall be put in place hand tight when cylinders are not in use or when they are being transported.</p> <p>Acetylene must never be operated at pressures greater than 15 psig.</p> <p>Do not allow an oxygen cylinder's pressure to fall below 50 psig. If the oxygen cylinder becomes empty, it will lose its positive pressure, and fuel gas may enter the oxygen equipment, which has the potential to produce an explosion.</p> <p>For non-fuel gas cylinders, e. g., oxygen, the cylinder valve should be opened fully. Failure to open the valve completely may cause leaks around the valve packing because of the design of the valve.</p>			

 Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

 Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control

LAI HAZARD ANALYSIS

Project Number:		Project Task: Hot Work				Location:					
Prepared By:				Date:		Reviewed By:				Date:	
Ref. Number	High Potential Consequence Task Steps	POTENTIAL HAZARDS & CONSEQUENCES Include applicable Error Prone Situations and Triggers	Target Check off to indicate Hold Point	Preliminary Risk Assessment			Control Type	SAFEGUARDS (Actions & Physical Safeguards) Eliminate or Mitigate the hazards	Final Risk Assessment		
				H	M	L			H	M	L
								For fuel gas cylinders (example: acetylene, MAPP Gas, Propane) open the valve approximately $\frac{3}{4}$ turn. Under no circumstances may the valve be opened more than $1 \frac{1}{2}$ turns. This is to allow for rapid closing should an emergency situation occur.			

Target: **P**=Personnel, **F**=Facilities and equipment, **E**=Environment

Control Type: **D**=Design hazard out or minimize, **E**=Engineering control, **S**=Safety device, **W**=Warning device, **A**=Administrative control